





Component details		
No.	Component	Quantity
1		1
2		26
3		8
		

Installation instructions



Power	Maintenance	
Model: 160010 Power: 220V-240V 50Hz/60Hz	1. please cut off the power supply. 2. the first house lizard into the wall and then hanging plate with self tapping screw lock into the house lizard with power line. 3. of the bulb is inserted in the lamp holder 4. open source.	